



# KRANMEISTER

## Roof stand and tile distributor

*...more than just a storage surface*



Aluminium roof stand

- **Light and easy to handle** during transport and on the roof
- Sturdy construction - high loads possible
- Versatile in use
- Precise work - place material where it is needed

### Roof tile spreader with slope adjustment

- Easy adjustment to the roof pitch due to practical grid adjustment
- Three pairs of rollers ensure a secure hold on the roof battens
- Extra-long castors for optimum load distribution on the roof surface
- Insertable side rail - can be stowed under the loading area to save space during transport



Roof tile spreader  
for crane operation



Roof tile spreader  
for elevator operation




# KRANMEISTER

## Roof stand and tile distributor

### Set up your building site

#### Aluminium roof stand

- Material or tools can be safely stored on two roof stands
- Simple tilt adjustment, 7-way adjustable
- Roof stand D1200 with large support surface for secure footing with 1200 mm parking depth



Type	Roof tile spreader		Roof tile spreader		Roof stand		
	CLASSIC	1 row	2 rows	BIG	D800	D1200	
Dimensions of the storage surface	480x950 mm	450x1250 mm	780x1250 mm	900x1250 mm	800 mm	1200 mm	
Load capacity	200 kg	200 kg	420 kg	640 kg	1000 kg*	1000 kg*	
Dead weight	13 kg	22 kg	42 kg	54 kg	5,5 kg	7 kg	
Adjustment range	----	0 - 60°	0 - 60°	0 - 60°	30° - 60°	30° - 60°	

\*Load capacity per pair

[www.trailercranes.co.uk](http://www.trailercranes.co.uk)

**The Trailer Crane Company**

Ladybird House, Hewell Lane

Redditch, Worcestershire, B97 6QS

Tel: 01527 889898 Email: [sales@trailercranes.co.uk](mailto:sales@trailercranes.co.uk)